

# Quick Start


Vapour Soft edited this page · [1 revision](#)

## Contence:

- [Home](#)
- [Building the Firmware \(optional\)](#)
- [Command Reference](#)
- [Flashing the firmware](#)
- [Hardware Assembly](#)
- [Notable Changes](#)
- [Quick Start](#)
- [Usage Notes](#)

## Starting...

1. Build the hardware - <https://github.com/VapourSoft/PCWWiFiModem/wiki/Hardware-Assembly>
2. Flash the firmware - <https://github.com/VapourSoft/PCWWiFiModem/wiki/Flashing-the-firmware>
3. Plug the modem into the PCW (ensure correct orientation and that the PCW is OFF)
4. Switch ON the PCW, boot CP/M, and check the hardware is detected:



CP/M Plus Amstrad plc  
v 2.9, 61K TPA, 2 disc drives, SIO/Centronics add-on, 1904K drive M:

5. Stay in CP/M and switch to your Locoscript disk. Type mail232 at the prompt which will load a basic comms program. Once loaded type ATI and press ENTER. You should see information about your newly built modem!